



HEBEL POWERFLOOR CONTROL JOINT DETAILS




RECOMMENDED CONTROL JOINT LOCATION
FOR ECCENTRIC LOADBEARING WALL
SCALE: 1:5



RECOMMENDED CONTROL JOINT LOCATION
FOR CHANGE IN JOIST ORIENTATION
SCALE: 1:5


HEBEL POWERFLOOR CONTROL JOINT DETAILS




CONTROL JOINT OVER BEARER/SUPPORT WALL

SCALE: 1:5

HEBEL POWERFLOOR CONTROL JOINT DETAILS



CONTROL JOINT DETAIL
OPTION 1
SCALE: 1:5



CONTROL JOINT DETAIL
OPTION 2
SCALE: 1:5